

Cutting and Sewing Instructions

011 Knit Leggings Sloper

Sizes 34, 36, 38, 40, 42, 44

Materials

Stretch fabric,

fabric width: 135 cm (53 ins)

fabric length: 1.00 m (1 1/8 yds) for all sizes.

A twin sewing machine needle.

3/4" wide elastic to be measured 1" less than your waist measurement length.

Recommended fabrics: Two or four-way stretch knit fabric. Use only very elastic fabrics.

Preparations

Print the pattern out on letter or A4 sized paper. It is very important to not scale or fit any of the pages, you must print the document in actual size. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to it's corresponding side. Then, tape down in place so paper is secure.

burda style magazine patterns do not have seam allowance included.


To be added:


Seams and edges 1/4" (for serged seams), hems 3/4"


Cutting Out

Stretch Fabric:

1 legging piece x2







Sewing

Lay legging pieces right sides together. Stitch centre front and centre back curved crotch seams.

Fold each leg right side facing in and stitch inseams as a continuous seam, matching up crotch points.

Stitch short ends of elastic together and stretch and sew into waist of legging. Turn into the wrong side and sitch in place with twin needle.

Turn in legging hems and stitch with twin needle.