

010 Knit Top/Dress Sloper

Sizes 34, 36, 38, 40, 42, 44

Materials

Stretch jersey,
width: 140 cm (55 ins)
length: 1.50 m (1 3/4 yds) for all sizes.

A twin sewing machine needle.

Recommended fabrics: Stretch jersey

Preparations

Print the pattern out on letter or A4 sized paper. It is **very important** to not scale or fit any of the pages, you must print the document in **actual size**. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to it's corresponding side. Then, tape down in place so paper is secure.

burda style magazine patterns do not have seam allowance included.



To be added:

Seams and edges 1/4" (for serged seams), hems 3/4"


Cutting Out

Stretch jersey:

1 front, on a fold	1x
2 back, on a fold	1x
3 sleeve	2x



Jersey



Fold the fabric as shown in the pattern layout, right side facing in.

Sewing

Stitch shoulder seams of front and back bodice. Stitch sleeves to arm-holes matching up the 6 notch.

Stitch seams of sleeve and side seams of bodice as one continuous seams matching up underarm points.

Turn up sleeve and body hem and stitch with twin needle. Finish the neck edge same way or use binding.